# **ETC SERIES**

# BATTERY CABINET INSTALLATION, OPERATION, AND MAINTENANCE MANUAL





This manual provides instructions regarding safety, storage, installation, operation and maintenance. Failure to observe the precautions as presented may result in injury or loss of life.

This document is proprietary to Electronic Systems Support (ESS). This document cannot be copied or reproduced in whole or in part, nor can its contents be revealed in any manner or to any person except to meet the purpose for which it was delivered, without the express written permission of Electronic Systems Support.

Please visit www.ess.to to check for updates to manual.



## **TABLE OF CONTENTS**

1. INTRODUCTION	. 2
2. PRECAUTIONS	
3. INSPECTION UPON RECEIPT OF GOODS	. 2
3.1 General	. 2
3.2 Visible damage	. 3
3.3 Concealed damage	
3.4 Return of damaged goods	. 3
4. SYSTEM OVERVIEW	. 3
5. GENERAL SYSTEM SPECIFICATIONS	
5.1 DC Output Characteristics	
5.2 Batteries	
5.3 Grounding	. 5
5.4 Environmental Conditions	. 5
Cabinet Dimensions	
Cabinet Weights (Assembled)	. 5
6. INSTALLATION PROCEDURES	. 6
6.1 Preparation	. 6
6.1.1 Necessary Equipment and Tools	. 6
6.1.2 Equipment Inspection	
6.1.3 Safety Precautions	
7. INSTALLATION STEPS	. 7
7.1 Cabinet Location	
7.2 Cabinet Mounting	
7.3 DC Connections	
7.4 Grounding	
7.5 System Operation	
8. SYSTEM MAINTENANCE	
8.1 Blown Fuse Replacement	
8.2 Battery Replacement Steps	. 8
9. WARRANTY RELATED MAINTENANCE	
10. DRAWINGS/SCHEMATICS	
General Cabinet Drawing (ETC40)	
General Cabinet Drawing (ETC36/ETC32)	
Anchor Specifications	
Anchor Placement Dimensions	. 13
ETC41 Battery Cabinet, Mechanical Drawing	. 14
ETC41, Electrical Drawing	. 15
ETC40 Battery Cabinet, Mechanical Drawing	. 16
ETC40, Electrical Drawing	. 17
ETC36, Mechanical Drawing	
ETC36, Electrical Drawing	. 19
ETC32, Mechanical Drawing	
ETC32, Electrical Drawing	
ETP41, Mechanical Drawing	
• ETP41, Electrical Drawing	
ETP40, Mechanical Drawing	
ETP40, Electrical Drawing	
ETP40, Electrical Drawing      ETP36, Mechanical Drawing	
ETP36, Nechanical Drawing      ETP36, Electrical Drawing	
·	
ETP32, Mechanical Drawing  ETP32, Floatical Drawing	
ETP32, Electrical Drawing	
Notes Page	
Notes Page	. 31



#### 1. INTRODUCTION

ESS ETC Series Top Terminal Battery Cabinets are shipped loaded with batteries partially assembled, internally pre-wired and come standard with an over current breaker. The removable hinged front doors and removable rear cover also allow for easier battery access. Refer to the battery layout drawings and schematics at the end of this manual. Consult the battery manufacturer's battery operation and maintenance manual for complete instructions.

These battery systems are built and tested to UL 1778 standards at the factory prior to shipment. All system settings are also adjusted at this time according to the specification sheet. Sales support for future equipment or upgrades is provided by our sales staff and qualified representatives. All technical questions and service issues should be directed to our office at 972-272-2468.

#### 2. PRECAUTIONS



 $ilde{m{m{m{m{\Delta}}}}}$  It is very important to read, understand and follow the instructions in this manual. Also note all SAFETY PRECAUTIONS before beginning the installation of this system.



 $ilde{m{m{\Delta}}}$  Consult the Battery Manufacturer's Operation and Maintenance Manual for important battery information.



A Battery cabinet systems are very heavy. Total weight can exceed 5,500 lbs, for a fully loaded cabinet. Use at least 3 people when unloading and setting equipment in place.



 $ilde{m{m{m{m{\Delta}}}}}$  It is imperative that only qualified personnel work on this system and installation, maintenance or upgrades be performed with insulated tools and equipment.



4 When installing this battery system, follow all applicable federal, state and local regulations and industry quidelines to insure a proper installation.



riangle DC power and battery supplies are dangerous and have extremely high short circuit currents. Severe burns or death can result from a system short. They also can leak potentially explosive gas (hydrogen). Never enclose batteries or battery cabinets in a sealed air tight room.



All jewelry and watches must be removed prior to installing or servicing this system.



(A) Do not smoke or present flame near or around any battery cabinet system.



A Never leave a panel off or door open and unattended.

#### 3. INSPECTION UPON RECEIPT OF GOODS

#### 3.1 General

Special precautions and care have been taken to ensure the cabinet system arrives safe and undamaged. However, upon receipt, you should inspect the entire shipment, including the crate and any boxes for evidence of damage that may have occurred during transit.



#### 3.2 Visible Damage

It is the responsibility of the person receiving the shipment to inventory and fully inspect all materials against the bill of lading or way bill IMMEDIATELY, while the carrier representative is still present. Ensure that all items are accounted for, including number of skids and quantity of boxes. Also note any visible external damage that may have occurred during transit. Make all applicable notations on the delivery receipt before signing even if notating "POSSIBLE CONCEALED DAMAGE" and file a damage report with the carrier.

#### 3.3 Concealed Damage

Immediately after receipt, unpack the cabinet system and check for any concealed damage. Check the materials received against the detailed packing list to verify the quantity and the condition as complete and satisfactory.

Note any damage to the internal packaging, then request an inspection by the carrier and file a concealed damage claim. If there is a material shortage, contact ESS at the number listed at the end of this manual.

Please contact your shipping company for all shipping damage. ESS is not responsible for any shipping damage.

#### 3.4 Return of Damaged Goods

A RMA number must be obtained before returning equipment to ESS. Please contact an ESS representative or call the corporate number listed at the end of this manual.

#### 4. SYSTEM OVERVIEW

The enclosed cabinet systems provide the necessary DC backup power required in UPS applications. Over-current breaker/fuse protection is supplied. DC connections are front accessible and made via terminal blocks and/or mechanical lugs. Refer to the drawings and schematics at the end of this manual for these connections. Cabinets are equipped with 3-pole breakers. There are 2 holes per polarity on 300 Amp to 600 Amp breakers. Breakers 30 Amps to 250 Amps have a single hole per polarity. It is recommended to use multiple runs of cables into cabinets and breakers where possible due to tight bend radius requirements inside the cabinets. See table below for standard output lug sizes of breakers.

BREAKER SIZING							
BREAKER SIZE AMPS	30A	40A	50A	75A	100A	125A	
A.I.C. RATING, 500DC	20,000 A.I.C						
OUTPUT LUG SIZE	(1)#14-3/0	(1)#14-3/0	(1)#14-3/0	(1)#14-3/0	(1)#14-3/0	(1)#4-3/0	
BREAKER SIZE AMPS	150A	175A	200A	225A	250A	300A	
A.I.C. RATING, 500DC	20,000 A.I.C						
OUTPUT LUG SIZE	(1)#4-4/0	(1)#4-4/0	(1)3/0-350	(1)3/0-350	(1)3/0-350	(2)2/0-500	
BREAKER SIZE AMPS	350A	400A	450A	500A	600		
A.I.C. RATING, 500DC	20,000 A.I.C						
OUTPUT LUG SIZE	(2)2/0-500	(2)2/0-500	(2)2/0-500	(2)2/0-500	(2)2/0-500		

During normal conditions the UPS supplies the load power and the necessary power required to keep the batteries at the proper float voltage. Verify that the charger is set to charge parameter s within the approved float voltage range of the batteries, refer to manufacturer's battery operation and maintenance manual.

When AC fails, the batteries discharge in order to provide the necessary backup power. It is the responsibility of the customer to make sure the batteries are not discharged below the battery manufacturer's recommendations. Always recharge batteries per manufacturer's battery operation and maintenance manual.



Batteries will be damaged if not recharged right away. See the UPS or DC system manual for more information.

#### 5. GENERAL SYSTEM SPECIFICATIONS

#### 5.1 DC Output Characteristics

• Voltage: (UPS Application) 48 to 480 VDC Nominal

Breaker: Standard

• **Fuse Type:** Not standard, consult factory. If a fuse is provided, it is only to be replaced by a factory service technician.

#### **CAUTION!** Fire Hazard Warning:

Replace only with same type and rating of fuses supplied with the system.

- Wire Size and Type: Per NEC and/or local building and electrical codes.
- **Disconnect:** If a fuse has been provided in lieu of a breaker inside the cabinet, a disconnecting method must be provided per NEC code. This may be a fuse switch or circuit breaker. Size accordingly.

#### 5.2 Batteries

- Type: Valve Regulated Lead Acid (VRLA), sealed, non-spillable.
- Voltage: 6 or 12 Volt DC Nominal, Top Terminal Design.

UL approved battery models:	III approved battery models:
Enersys12HX205	UL approved battery models: CSB HRL SeriesHRL12110W
Enersys12HX300	CSB HRL SeriesHRL12150W
	CSB HRL SeriesHRL12200W
Enersys12HX330	CSB HRL SeriesHRL12280W
Enersys12HX400	CSB HRL SeriesHRL12230W
Enersys12HX505	CSB HRL SeriesHRL12390W
Enersys12HX540	
Enersys6HX800	CSB HRL SeriesHRL12500W
C&D Dynasty UPS HRUPS12-210MR	CSB XHRL SeriesXHRL12360W
C&D Dynasty UPS HRUPS12-300MR	CSB XHRL SeriesXHRL12410W
C&D Dynasty UPS HRUPS12-350MR	CSB XHRL SeriesXHRL12475W
C&D Dynasty UPS HRUPS12-400MR	CSB XHRL SeriesXHRL12620W
C&D Dynasty UPS HRUPS12-490MRLP	Fiamm12FLX200
C&D Dynasty UPS HRUPS12-490MR	Fiamm12FLX250
C&D Dynasty UPS HRUPS12-540MR	Fiamm12FLX300
C&D Dynasty UPS HRUPS12-600MR	Fiamm12FLX300
C&D Dynasty UPS HRUPS6-620MR	Fiamm12FLX350
GNB SprinterS12V120F	Fiamm12FLX400
GNB SprinterS12V170F	Fiamm12FLX450
GNB SprinterS12V285F	Fiamm12FLX540
GNB SprinterS12V300F	Interstate MarquisMQ800
GNB SprinterS12V370GNF	Interstate MarquisMQ1200
GNB SprinterS12V500F	Interstate MarquisMQ1800
GNB SprinterS12V550GNF	Interstate MarquisMQ2100
GNB SprinterS6V740GNF	Interstate MarquisMQ2400
Deka Unigy High Rate45HR2000	Interstate MarquisMQ3000
Deka Unigy High RateHR3000	Interstate MarquisMQ4100
Deka Unigy High RateHR3500	Northstar BatteryNSB12-310
Deka Unigy High RateHR4000	Northstar BatteryNSB12-425
Deka Unigy High Rate31HR5000	Northstar BatteryNSB12-540
Deka Unigy High RateHR5500	·

Only cabinets with flame retardant batteries are suitable for computer room use.



#### 5.3 Grounding

- All grounding should be derived from the main building ground source.
- Note: All cabinet systems require grounding.
- All cabinets have a defined ground connection point.

#### 5.4 Environmental Conditions

Breakers are located at the top of the cabinet.

#### Standard Cabinet Dimensions:

```
ETC41 Top Breaker is 40.0^\circ W x 29.5^\circ D* x 78.7^\circ H (applies to ETP41) ETC40 Top Breaker is 40.0^\circ W x 29.5^\circ D* x 78.7^\circ H (applies to ETP40) ETC36 Top Breaker is 36.0^\circ W x 29.5^\circ D* x 78.7^\circ H (applies to ETP36) ETC32 Top Breaker is 32.0^\circ W x 29.5^\circ D* x 70.9^\circ H (applies to ETP32)
```

For mounting hole dimensions, please refer to the cabinet layout drawing at the end of this manual.

#### Max Cabinet Weights: (Assembled)

(Based on 540 Ah batteries unelss specified)	VDC	# of Blocs
•		
ETC41XX41 is 5,011 lbs.	492	41
ETC41XX40 is 4,905 lbs.	480	40
ETC41XX32 is 4,057 lbs.	384	32
ETC40XX41 is 4,991 lbs.	492	41
ETC40XX40 is 4,885 lbs.	480	40
ETC40XX32 is 4,037 lbs.	384	32
ETC36XX40 is 4,850 lbs.	480	40
ETC36XX32 is 4,002 lbs.	384	32
ETC36XX30 is 3,790 lbs.	360	30
ETC36XX24 is 3,154 lbs.	288	24
ETC32XX32 is 3,942 lbs.	384	32
ETC32XX30 is 3,730 lbs.	360	30
ETC32XX24 is 3,094 lbs.	288	24
ETC32XX20 is 2,680 lbs.	240	20
ETP41XX40 is 5,105 lbs.	480	40
ETP40XX40 is 5,085 lbs.	480	40
ETP36XX40 is 3,982 lbs.	480	32
ETC32XX32 is 3,130 lbs.	384	32 (based on 400 WPC batteries

<sup>\*\*</sup>Consult with factory for additional configurations.

- **Temperature:** Normal operating temperatures are between 68°F -77°F. **Note:** Batteries typically should be at 77°F for optimum battery life and performance.
- Ventilation/Cooling: Provided through ventilation slots in the rear panel, bottom panel, and top of
  cabinet, thus providing a chimney effect for natural convection cooling. If local codes require forced
  air exhaust, unused covers serve as conduit entry or duct work entry points. Fan kits are also
  available from ESS.
- Clearance: A minimum of four inches is required in both the front and the rear of the cabinet. This refers to obstruction of ventilation only. Clearance around cabinet sides is suggested by NEC and local codes.

<sup>\*</sup> All depth dimensions are of the cabinet only. The exterior breaker handle (optional) extends from the front of the cabinet 2.25"; consider this distance when calculating aisle space in front of the cabinet.



#### **CAUTION!** Explosion/Fire Hazard Warning:

Batteries can generate potentially explosive gas (hydrogen). Never enclose batteries or battery cabinets in a sealed, airtight room.

#### 6. INSTALLATION PRODEDURES

#### BEFORE PROCEEDING WITH INSTALLATION READ THE FOLLOWING:

#### 6.1 Preparation

#### 6.1.1 Necessary Equipment and Tools

- Rigging tools for moving cabinets. Pallet jack and forklift of 5,500 lbs. minimum capacity.
- Heavily insulated assortment of hand tools.
- Digital Voltmeter

#### 6.1.2 Equipment Inspection

Remove the packaging material from the cabinet and inspect for any concealed shipping damage that may have been overlooked upon receipt of goods. Use the packing list to verify the system has all components and cables for installation.

#### 6.1.3 Safety Precautions


#### DC VOLTAGE WARNING!

Hazardous DC Voltages are present in the battery cabinet. This hazard will always be present, even when the battery system is off-line. Accidental short circuit of the positive and negative terminals will cause tremendous currents to flow resulting in severe burns, fire and possible death. Use extreme caution!

#### **IMPORTANT SAFETY INSTRUCTIONS. SAVE THESE INSTRUCTIONS!!**




All disconnecting means should be in the open/off position before servicing.









Do not rest any tools or loose cables on top of batteries.

Make sure all connections are properly torqued and secure. Torque values are provided on battery label.

(A) Do not smoke or present flames near or around any battery system.

Always wear safety glasses and gloves and use insulating mats to stand on when working on this system.





Do not allow bare skin to come into contact with battery cabinet, as this could result in an electrical shock.



Do not install any cable terminations until it has been verified that such a termination will not create a short circuit.

#### 7. INSTALLATION STEPS

#### 7.1 Cabinet Location

Prior to installation, verify floor loading requirements and all applicable codes pertaining to the related equipment. Environmental conditions should also be reviewed. Proper ventilation and cooling must be adequate for optimum battery life and performance. A clearance of 4" is recommended at the front and rear of the cabinet. This refers to obstruction of ventilation only. Clearance around the cabinet sides should be as suggested by NEC and local codes. Ambient temperature should be between 68°F -77°F.

#### 7.2 Cabinet Mounting

- 1. Remove any remaining packaging materials (cardboard, plastic).
- 2. Unbolt the cabinet from the pallet. Remove the cabinets from the pallet using a forklift rated for at least 5,500 lbs.
- 3. The battery cabinet is equipped with narrow pallet jack or forklift access openings in the front and rear of the cabinet. Move the equipment into the desired location and set in place.
- 4. In order to meet seismic requirements, refer to the SEISMIC ANCHORING drawings included with this manual. The following steps detail the necessary actions to be taken to meet Zone 4 mounting requirements.
- 5. For safety purposes, all cabinets must be anchored to floor per local building codes. Use Seismic anchors for seismic applications. Use standard concrete anchors for standard installations.
- 6. On the floor, mark the location of the 6 mounting holes found at the bottom of the cabinet legs.
- 7. Use the hole location drawing provided with each shipment to mark holes for anchors. Use ½" or 13mm anchors. Install anchors per manufacturer's instructions.
- 8. Move the cabinet into place, align holes, check levelness, and tighten hardware. **Note:** Should any drilling be performed on this equipment, make sure all exposed batteries and connections are completely covered using insulated type mats. Prevent dust from entering cabinets and clear any debris that has collected.
- 9. Install the front doors on the cabinet.
- 10. If multiple battery cabinets are installed, repeat above steps. Check height and levelness with adjoining cabinets.

#### 7.3 DC Connections

#### **CAUTION!** PLEASE READ ALL SAFETY INSTRUCTIONS BEFORE PROCEEDING.

- 1. Open the cabinet door and check for any noticeable problems or damage that may have occurred during shipment.
- 2. Review the installation drawing and schematic diagram included in this manual. Cables and bus bars have been left off in the battery string for safety and will need to be installed later.
- 3. Connect main cables to the circuit breaker, when applicable, inside the cabinet from the UPS or charger source. All cables should be sized per NEC and any other local codes pertaining to this equipment. Refer to the UPS or charger manual for wiring external batteries. Note: Make sure charging source is disconnected before making these connections; also verify the battery cabinet is turned off.



4. Connect the battery interconnect cables that were left off during shipment and install as shown on the installation drawing included in this manual. Torque connections properly. Torque values are provided on battery label.

#### 7.4 Grounding

Ground the battery cabinet to the main building ground. A ground stud inside the cabinet is provided for this.

#### 7.5 System Operation

Refer to the UPS or charger manual for start up and operation of system.

#### 8. SYSTEM MAINTENANCE

# <u>CAUTION!</u> PLEASE READ ALL SAFETY PRECAUTIONS BEFORE PROCEEDING

#### 8.1 Blown Fuse Replacement

If a fuse has blown in the system, contact an authorized factory technician to replace it.

#### **CAUTION! Fire Hazard Warning:**

Replace only with same type and rating of fuses supplied with the system.

#### 8.2 Battery Replacement Steps

Servicing of batteries should be performed or supervised by personnel knowledgeable about batteries and the required precautions. When replacing batteries, replace with the same type and number of batteries.

#### **CAUTION!**

Do not dispose of batteries in a fire. The batteries may explode.

Do not open or mutilate batteries. Released electrolyte is harmful to the skin and eyes. It may be toxic.

A battery can present a risk of electrical shock and high short-circuit current. The following precautions should be observed when working on batteries:

- · Remove jewelry, rings, watches or other metal objects.
- Use tools with insulated handles.
- Wear rubber gloves and boots. Wear safety glasses.
- Do not lay tools or metal parts on top of batteries.





- Disconnect charging source prior to connecting or disconnecting battery terminals.
- Determine if the battery is inadvertently grounded. Remove string from buss and check voltages to ground. Contact with any part of a grounded battery can result in electrical shock. The likelihood of such shock can be reduced if grounds are kept during installation and maintenance.
- 1. Prepare the new battery for installation. Check to make sure the battery is the same type and amphour rating. Use a non-metallic brush or scotch brite pad to clean the terminals. Apply a light coat of No-ox grease to the terminal to avoid corrosion "per battery manufacturer's recommendation".
- 2. Disconnect the charger or UPS from the battery string by opening the breaker.
- 3. Remove the center jumper on the battery string to reduce the voltage. If replacing all batteries, continue reducing the voltage in this manner.
- 4. Disconnect the interconnect bus bars and/or cables from the battery to be replaced.
- 5. Remove the old battery.
- 6. Install the new battery. Make sure the new battery is installed the same way regarding polarity orientation and verify with drawing.
- 7. Reconnect cables to the battery. Make sure connections are properly torqued. Torque values are provided on the battery label.
- 8. Reconnect the center jumper. Make sure connections are properly torqued. Torque values are provided on the battery label.
- 9. Check voltage at terminal block.
- 10. Close breaker when ready. If your model has a disconnect with an exterior handle to the door, close and latch on the door first before closing the breaker.


#### 9. WARRANTY RELATED MAINTENANCE


- The purchaser (user) shall give freshening charges to the battery a minimum of every six (6) months for Lead-Calcium batteries after shipment from the factory and until final installation. Refer to the installation and maintenance instructions from the battery manufacturer for maximum storage intervals at different environmental situations. Extreme heat could cause more frequent freshing charges.
- 2. At least once every six (6) months, purchaser (user) must take readings and record information per battery manufacturer's installation/maintenance instructions. These records must be maintained for warranty claim purposes. If warranty records are not kept, the warranty shall be null and void.
- 3. Parallel strings should be limited to five (5) strings.
- 4. Movement of batteries from original point of installation shall immediately void the product warranty, except with the expressed written consent from ESS.
- 5. Any storage shall be in a dry area having ambient temperature of 77° F (25° C), or less, and in accordance with battery manufacturer published installation, operation and maintenance instructions. Failure to follow the battery manufacturer's published guidelines and/or instructions may invalidate the product warranty, at the sole discretion of ESS.
- 6. During service or extended storage, a battery system monitor is recommended to be used to record temperatures, voltages, AC ripple, Float currents, Discharge and more to provide more accurate battery and environmental data for warranty with battery manufacturer's claims.











































































www.ess.to











### **NOTES**

## **NOTES**

